Dishmachine Procedures when Dealing with an Outbreak



Low Temperature Machines











- Wash and rinse temperatures are to be a minimum of 120°F. This is controlled by the incoming water to the machine. If the temperature drops below that, there are no adjustments on the machine to raise the temperature. Incoming water temperature is controlled by the customer.
- · There are no minimum requirements for the level of detergent used in the wash cycle. A Santec technician will set your detergent at an appropriate level to remove soils and keep them suspended until they can be washed away down the drain. Best practices are to minimize the amount of soils going into the dishmachine by using good pre-scraping procedures.
- Rinse requires a minimum temperature of 120°F. This is regulated by the incoming water to the machine and is controlled by the the customer.
- An EPA registered sanitizer is used in the rinse cycle to sanitize the surfaces. This is typically a chlorine based product. The active chlorine in the rinse solution must be between 50-100 parts per million (ppm). Santec recommends a setting of 75-100 ppm to ensure the level does not drop below 50 ppm due to normal wear and tear of the dispenser squeeze tube.
- Temperature and chlorine levels should be checked and recorded daily although Santec recommends doing this at the start of each shift.
- · Cleaned items need to be completely air dried before storing and should be handled minimally to avoid any contamination. Additionally, hands should be washed prior to handling clean items.

High Temperature Machines









- The rinse temperature needs to be a minimum of 180-197°F at the temperature gauge. This can be adjusted by your Santec technician at the booster heater used to raise the incoming water supply temperature. •Sanitation is achieved by raising the surface temperature of the items in the dishmachine to a minimum of 160°F. This can be verified by using a nonreversible temperature test strip or a dishmachine temperature plate. •Temperature should be checked and recorded daily although Santec recommends doing this at the start of each shift.
- •Cleaned items need to be completely air dried before storing and should be handled minimally to avoid any contamination. Additionally, hands should be washed prior to handling clean items.

For more information, please contact your SFS sales representative or Santec technician.