

Pot and Pan Procedures when Dealing with an Outbreak

Three Compartment Sink: Wash, Rinse & Sanitize



Pot and Pan Cleaning and Sanitizing Procedures:

- Fill **WASH** sink with Santec's automatic dispenser like our Dema 652Gap and Viking Sink Bowl or manually adding hot water and Santec detergent. The solution in the **WASH** sink should be at the temperature specified on Santec detergent.
- Fill **RINSE** sink with hot water.
- Fill **SANITIZE** sink with lukewarm water. Add Santec sanitizer. The **SANITIZE** sink solution should be mixed at a concentration specified on Santec sanitizer. Test the chemical sanitizer concentration by using an appropriate test kit.
 - **WASH** - Pre-scrape pots and pans. Soak for at least 5 minutes. Scrub all surfaces. Let extra water run back in **WASH** sink.
 - **RINSE** - Submerge in hot water **RINSE** sink. Let excess water run back in RINSE sink.
 - **SANITIZE** - Submerge in **SANITIZE** sink for 1-2 minutes. Air dry by removing from the **SANITIZE** sink. Turn upside down to air dry. Do not wipe dry.

Requirements and Recommendations for the Three Compartment Sink Procedures:

- Clean and sanitizer all compartments and drain boards before each use.
- Please be aware do not wash hands or mops in the Three Compartment Sink.
- An EPA registered sanitizer is used in the **SANITIZE** sink to sanitize the surfaces. Recommended at an active quaternary concentration of 200-400 ppm when diluted in water up to 650 ppm hardness. Santec Sales Representative will provide the correct parts per million (ppm) for the **SANITIZE** sink.
- Temperatures and chlorine levels should be checked and recorded daily although Santec recommends doing this at the start of each shift.
 - **Hydriion QT-10 Instructions (Sanitization Range Testing)**
 - Withdraw and tear off approximately 2 inches of paper from dispenser.
 - Testing solution should be at room temperature.
 - Dip paper for 10 seconds Don't shake.
 - Compare colors immediately with colors on the test strip package to determine ppm. Always compare against package scale.
 - Testing solutions should be between 200-400 ppm.
- Cleaned items need to be completely air dried before storing and should be handled minimally to avoid any contamination. Additionally, hands should be washed prior to handling clean items.



Suggested Santec Cleaning Products for the Three Compartments Sinks

- Resolve Seven - Concentrated Pot and Dish Detergent
- Resolve Eight - Disinfectant and Sanitizer (EPA No. 1839-86-84179) *N-List Approved*

For more information, please contact your sales representative.